





1) Innenschirm  
Internal shield  
Blindage interne  
Schermo interno  
Blindaje interno

1	2	5	6	7	8	3	4	Schirm Shield Blindage Schermo Blindaje	9
$I_1$		$I_2$		$I_0$		5V $U_P$	0V $U_N$		1)
+	-	+	-	+	-				






# HEIDENHAIN

Montageanleitung  
Mounting Instructions  
Instructions de montage  
Istruzioni di montaggio  
Instrucciones de montaje

## ST 1207 ST 1208

5/2004

$U_P = 5V \pm 10\%$   
( $25 \pm 10$  mA)  
EN 50 178  
PELV  $\frac{1}{2}$  EN 60204-1



**DR. JOHANNES HEIDENHAIN GmbH**  
Dr.-Johannes-Heidenhain-Straße 5  
83301 Traunreut, Germany  
☎ +49 (8669) 31-0  
☎ +49 (8669) 5061  
E-Mail: info@heidenhain.de

**Technical support** ☎ +49 (8669) 32-1000  
**Measuring systems** ☎ +49 (8669) 31-3104  
E-Mail: service.ms-support@heidenhain.de  
**TNC support** ☎ +49 (8669) 31-3101  
E-Mail: service.nc-support@heidenhain.de  
**NC programming** ☎ +49 (8669) 31-3103  
E-Mail: service.nc-pgm@heidenhain.de  
**PLC programming** ☎ +49 (8669) 31-3102  
E-Mail: service.plc@heidenhain.de  
**Lathe controls** ☎ +49 (8669) 31-3105  
E-Mail: service.lathe-support@heidenhain.de

[www.heidenhain.de](http://www.heidenhain.de)

### SALES & SERVICE:

**A Tech Authority, Inc.**  
13745 Stockton Ave.  
Chino CA 91710  
909-614-4522  
sales@atechauthority.com



